




DETAIL OF POSITION THE METAL THUMB OPPOSITE TO SENSOR S01

A(5:1) RPM 1000/min    A(5:1) RPM 4000/min    A(5:1) RPM 6000/min



ATTENTION:

FOR CORRECT WORKING THIS IGNITION SET IT IS NECESSARY TO HAVE IN RIGHT THE CHARGING SYSTEM. THE BATTERY HAVE CONNECT TO GROUND BY NEGATIVE CONTACT. IN OPPOSITE CASE THE IGNITION COIL WILL BE DAMAGED. IT IS NOT TO REPAIR. THE HOT AIR MUST NOT RADIATE TO IGNITION COIL. WHEN THE MOTORCYCLE IS RIDING, THE IGNITION COIL IS COLDED BY CURRENT OF AIR. THE REPLACEMENT BETWEEN YELLOW AND RED CABLE DO NOT CAUSE DAMAGE THE IGNITION COIL. HIGH VOLTAGE IN THIS SITUATION IS NOT GENERATED.

If you want to use this ignition coil for one cylinder engine, connect to ground the high voltage output, which is near the two input cables.

Kusů	Název - rozměr	Jakost	Norma	Tř. odp.	Hmotnost kg	Povrch dm <sup>2</sup>	Číslo výkresu - podstava	Pozice
Poznámka : CONTACTLESS IGNITION JAWA 350;							Povrchová úprava	
Měřítko	System	AutoCAD 2000	Typ	MZO4	Číslo kopie	Změna	Datum	Podpis
	Kreslil	Vrbka						
	Schválil							
	Dne	11.7.2007						
Název výkresu					Nahrazuje v.č.			
SET: 12V IGNITION COIL WITH TWO HIGH VOLTAGE OUTPUTS					Číslo výkresu			
INSTRUCION MZO4					Formát A 3			
					Počet listů			
					List			

